

Instructions for normal use of your system

ARMING

To arm your system when no one is going to be in the building: From your home screen, press the “Security” button, then press “Away”.

The difference between the “Away” and “Stay” modes, is that in the “Stay” mode, your motion detectors will not be active.

DISARMING

To disarm your system when you return: When you walk into the building, after being away, a keypad will be displayed on your screen. Simply enter your 4-digit code, and the system will disarm.

HOW TO CLEAR AN ALARM SO THE SYSTEM CAN BE REARMED

1. From the home screen, touch the “Security” button.
2. Touch the “Display Faults” button.
3. If there is an alarm that needs to be cleared out, there will be a button towards the bottom of the screen that says “Clear”. Touch the “Clear” button, and then enter your code.

SPECIAL NOTES

When disarming your system, if you enter the wrong code by accident, simply touch the “Clear” button (it will be at the lower left of your screen) and re-enter your proper code.

If, for some reason, a zone is giving you a fault (and nothing seems obviously wrong with it) you can bypass the zone until it can be repaired. To bypass a zone, follow these steps: From your home screen press “Security”. On the right side of the screen you will see “Display Fault”. Press this button, and it will display which zone is faulted. At the bottom of your screen you can touch “Bypass”, then enter your code. When the system is disarmed in the morning, the bypass will no longer be in effect, so you may have to bypass again when you arm the system.